

Train Order Working

ESD-08-01

Applicability

ARTC Network Wide

Publication Requirement

Internal / External

Primary Source

SDS 19

Document Status

Version #	Date Reviewed	Prepared by	Reviewed by	Endorsed	Approved
1.8	22 Dec 20	Standards	Stakeholders	Manager Signalling Standards	General Manager Technical Standards 22/12/2020

Amendment Record

Amendment Version #	Date Reviewed	Clause	Description of Amendment
1.0	27 Apr 09		First issue. Supersedes NSW Standard SDS 19 v2.0
1.1	07 Oct 09		Disclaimer updated as per Risk & Safety Committee 14/09/2009
1.2	13 Aug 10	All	Issued as final.
1.3	11 Oct 11		Changes for TOW network control boundaries 1.1.12, 1.8, 1.2.2 and alternate points track circuits 1.3.3. Update to 1.3.3 to delete reference to high voltage impulse type track circuits following endorsement from OS&ERG 11/10/11.
1.4	30 Aug 13	1, 2.13, 2.14, 2.19, 3.9, 4.3 & 5.3	Changes for PTOS Operation and Format Update.

© Australian Rail Track Corporation Limited (ARTC)

Disclaimer

This document has been prepared by ARTC for internal use and may not be relied on by any other party without ARTC's prior written consent. Use of this document shall be subject to the terms of the relevant contract with ARTC.

ARTC and its employees shall have no liability to unauthorised users of the information for any loss, damage, cost or expense incurred or arising by reason of an unauthorised user using or relying upon the information in this document, whether caused by error, negligence, omission or misrepresentation in this document.

This document is uncontrolled when printed.

Authorised users of this document should visit ARTC's intranet or extranet (www.artc.com.au) to access the latest version of this document.

1.5	31 Jul 14	1.3 & 1.5	Minor editorial update to delete blank definitions table and add SFAIRP definition in text.
1.6	07 Dec 16	1.1, 1.2, 1.4, 2, 2.1, 2.2, 2.3, 2.4, 2.5, 2.6, 2.8, 2.9, 2.10, 2.11, 2.15, 2.16, 2.17, 2.18, 2.19, New section 4, 11, 11.1, 11.4.2, 11.5	Addition of Electronic Authority – Advanced Train Management System updates to various sections and new section 4. Minor amendments to original standard due to clerical and diagram issues. Also updated to include items from the Issues Register and updates to reflect naming conventions within the CoP.
1.7	26 Jun 20	2.3, 2.5, 2.7.2, 2.9, 2.17.2, 2.17.4, 2.20, 2.22, 3.2, 3.9, 5.3.1, 5.5, 6.4, 8.5, 8.6 11.1 and 12	Change to section 12 to clarify requirements for complex locations and consideration to provide RVD signalling in lieu of TOW. Other minor corrections and clarifications.
1.8	22 Dec 20	1.1, 1.2, 1.3, 1.4, 2, 3.6 & 4	Removed references to ATMS. Now separate Standard ESD-08-02.

Table of Contents

Table of Contents	3
1 Introduction.....	6
1.1 Purpose	6
1.2 Scope	6
1.3 Responsibilities	6
1.4 ARTC Reference Documents.....	6
2 Train Order Working Infrastructure	7
2.1 Introduction to TOW	7
2.2 Location Ahead Sign	7
2.3 Yard Limit Signs	8
2.4 Shunt Limit Signs	8
2.5 Clearance Posts	9
2.6 Point Indicators.....	9
2.6.1 <i>Mechanical</i>	9
2.6.2 <i>Electrical</i>	10
2.7 Points Setting Indicator	10
2.7.1 <i>Point Setting Indicators - not on the main line</i>	11
2.8 Main Line Indicators/Repeaters	11
2.9 Light Indicators	13
2.10 "Start" or "Begin Train Order Working" Sign	14
2.11 "End Train Order Working" sign	15
2.12 Network Control Boundary Location signs.....	15
2.13 Ground Frames	16
2.14 Operating Keys.....	16
2.14.1 <i>Operators Key</i>	16
2.14.2 <i>Master Key</i>	17
2.14.3 <i>Inspection Key</i>	17
2.14.4 <i>Safes for Keys</i>	17
2.15 Landmarks.....	17
2.16 Shunting Limit or Stop Signs.....	18
2.17 Block Location Name Signs	18

2.18	Train Order Kilometrage Signs.....	18
2.19	Derailers.....	18
3	Types and Layout of Train Order Locations.....	20
3.1	Introduction.....	20
3.2	Types of Train Order Locations - NSW.....	20
3.3	Mechanical Point Indicators (MPI).....	22
3.4	Main Line Indicators (MLI).....	22
3.5	Repeaters to Main Line Indicators.....	23
3.6	Closely Spaced Train Order Locations.....	23
3.7	Provision of Additional Main Line Indicators within Train Order Locations.....	25
3.8	Naming of Ground Frames at Train Order Locations.....	25
4	Train Order Locations with Motorised Points.....	26
4.1	Introduction.....	26
4.2	General Arrangement.....	26
4.3	Track Locking.....	26
4.3.1	<i>Types of track circuits used for Track Locking.....</i>	<i>26</i>
4.3.2	<i>Extent of Track Circuit Locking.....</i>	<i>27</i>
4.4	Point Setting.....	27
4.5	Emergency Operation of Points.....	27
4.6	Use of Repeating Indicators.....	27
5	Level Crossings at Train Order Locations.....	28
5.1	Introduction.....	28
5.2	Arrangement where the Level Crossing is some distance from the Loop/Siding.....	28
5.3	Arrangement where the Level Crossing is close to the Loop/Siding.....	29
5.4	Arrangement with Sidings on each side of the Level Crossing.....	30
5.5	Specific Provisions for Passenger or Stopping Trains.....	31
5.6	Level Crossings at Locations Equipped with Main Line Indicators.....	31
6	Junctions at Train Order Locations.....	32
6.1	Introduction.....	32
6.2	Normal Arrangement.....	32
6.3	Arrangement using Mechanical Trailable Points.....	32
6.4	Arrangement using a Both-Ways Lock.....	32
6.4.1	<i>Arrangement with Mechanical Indicators.....</i>	<i>32</i>
6.4.2	<i>Arrangement with Main Line Indicators.....</i>	<i>33</i>

6.5	Arrangement using Motorised Points	33
7	Arrangements of Infrastructure at Train Order Boundaries	35
7.1	Introduction.....	35
7.2	Arrangement where Shunting Outside of the Home Signal is Not Required	35
7.3	Arrangement where Shunting Outside the Home Signal is Required.....	35
7.4	Arrangement where a Dedicated Starting Signal is provided	36
7.5	Arrangement where a “Shunt Limit” Sign is provided	37
7.6	Arrangement with a Siding within a Train Order Location adjacent to a Signalled Interlocking ..	38
8	Infrastructure Arrangements at Line Termini worked by Train Orders	40
8.1	Introduction.....	40
8.2	Arrangement where a Train Order Section is adjacent to a Non-Interlocked Area	40
8.3	Arrangement where Terminus is a Train Order Location.....	41
9	Infrastructure Arrangements at a Network Control Boundary Location	42
9.1	Introduction.....	42
9.2	General Arrangement.....	42
10	Train Order Locations with Motorised Points, Light Indicators and ICAPS System.....	43
10.1	General Arrangement.....	43
10.2	Track Locking.....	43
10.3	Point Setting.....	43
10.4	Operating Points from Local Control	44
	10.4.1 Push Button Controls:.....	44
	10.4.2 Indicator Lights:	44
10.5	Operating Points from a Locomotive.....	45
11	Locations to be considered for normal Rail Vehicle Detection Signalling instead of Train Orders	46
11.1	Introduction.....	46
11.2	Conditions that may not be fulfilled by Train Order Infrastructure	46

1 Introduction

1.1 Purpose

The requirements for the provision of Train Order Working as required by ARTC safeworking policies.

Train Order Working is a system of safeworking in which written authorities for the occupancy of the track and movement between Block Locations are issued to, and acted upon, by train crews.

An Authority is issued when rail traffic departs a section or a block location to enter a siding. This is relinquished when the rail traffic is in clear and the points restored. The rail traffic may shunt within the siding.

Train Order Working signs and indicators are provided to identify Train Order Working territory limits, Block Locations, point settings and other limits.

1.2 Scope

This standard covers the use of Train Order Working - as new implementations with a computer safety system providing safety to the issuing of Train authorities.

1.3 Responsibilities

The General Manager Technical Standards is the Document Owner. For any query, initial contact to be made at standards@artc.com.au. The Signal Designer is responsible for the implementation of this standard in any new signalling designs.

The Signal Design Manager is responsible for managing the process and ensuring consultation with stakeholders. The Signal Design Manager is responsible that the signalling design meets the operational requirements and are safe So Far as is Reasonably Practicable (SFAIRP).

1.4 ARTC Reference Documents

The following documents support this standard:

- Victorian Rule book TA20
- ESD-03-01 Level Crossing Design
- ESD-05-01 Common Signal Design Principles S1
- ESD-08-03 Placement of Yard Limit Signs
- New South Wales Network Rules
- Code of Practice for the Defined Interstate Rail Network – Volume 3 Operations and Safeworking Part 1 Rules
- ARTC Addendum to the Code of Practice

2 Train Order Working Infrastructure

2.1 Introduction to TOW

Train Order Working is a system of safeworking in which written authorities for the occupancy of the track and movement between Block Locations are issued to, and acted upon, by train crews.

An Authority is issued when rail traffic departs a section or a block location to enter a siding. This is relinquished when the rail traffic is in clear and the points restored. The rail traffic may shunt within the siding.

Train Order Working signs and indicators are provided to identify Train Order Working territory limits, Block Locations, point settings and other limits.

2.2 Location Ahead Sign

Location Ahead Signs are provided in TOW territory. This is a triangular shaped retro-reflective yellow sign and indicates that a Block Location is being approached.

A plate, with black lettering on a yellow background, is fitted to the post with the name of the location to which it refers.

Alternatively, a single plate showing both the triangle and location name may be used – they will be replaced with the above-mentioned signs over time.

Where the location name is long or consists of more than one word, the lettering must not be reduced, but the sign may have more than one line of writing. Punctuation must not be included in the name.

Both the location sign and name plate are to have the reverse side coloured non-reflective matt grey.

The distance from the Location Ahead sign to the Yard Limit sign is indicated on the bottom of the triangle. Signs in some areas may not have the distance indicated. These will be replaced over time.




Figure 2-1: LOCATION AHEAD SIGN

2.3 Yard Limit Signs

Yard limits signs are provided in TOW territory. Yard Limit signs define the geographical limits of a train order Block Location. Yard Limit boards also define points to which an authority may be issued, as set out in the Network Rules.

These signs are retro-reflective with the words “YARD LIMIT” in black letters on a white background. The reverse side of the sign may have either the words “YARD LIMIT” or a black cross on a white background.




Figure 2-2: YARD LIMIT SIGN

2.4 Shunt Limit Signs

Shunt limit signs are provided in TOW territory.

Shunt Limit signs define shunting limits at a Block Location. At locations where no crossing loop exists, Shunt Limit boards also denote the extents of the ‘Main’ line at that location. In TOW territory, Shunt Limit signs also define points to which an authority may be issued, as set out in the Network Rules.

These signs are retro-reflective with white letters on a red background. The reverse side of the sign must be non-reflective matt grey.

Note: Signs in some areas may have black letters on a white background. These will be replaced over time.




Figure 2-3: SHUNT LIMIT SIGN

All new design/installation to use the preferred ‘Limit of Shunt’ sign.

Back

2.5 Clearance Posts

Clearance post signs shall be provided in TOW territory. Clearance Posts denote the limits of the Main Line and Crossing Loop lines at a Block Location. Clearance Posts also define points to which an authority may be issued, as set out in the Network Rules.

Clearance Posts are placed at the clearance point between, or on the outside of the Main Line and Crossing Loop. Clearance Posts shall be positioned in accordance with the Track & Civil Code of Practice Section 7: Clearances.

The Clearance Post may take the form of a round post on which a black 'C' is displayed on a white retro-reflective background on both sides of the post, or as a sign, on which black letters 'CP' are displayed on a white retro-reflective background on both sides of the sign.

Clearance Posts are not required to be numbered in TOW territory.




Figure 2-4: CLEARANCE POST

2.6 Point Indicators

Point indicators are provided for in TOW territory.

Points indicators only provide an indication of the setting and security of points. They do not provide an Authority for the movement, which is provided by the written Authority (Train Order) territory.

2.6.1 Mechanical

Mechanical Point Indicators are provided to give an indication to the driver that a particular set of points are set and locked, either:

- For the normal direction movement, where the points can be locked in only one position, or
- For either direction, where the points may be locked in either position, in which case a Points Setting Indicator will also be provided to indicate the direction for which the points are set.

Mechanical Point Indicators do not constitute a signal, and do not provide a movement authority to a train, the train movement itself is made on the authority of the Train Order.

The indication is displayed by a retro-reflective white bar provided against a square black background. The bar is inclined to 45° when the points are set and locked. The bar is horizontal when the points are unlocked. The indicator is normally double sided.

Mechanical Point Indicators of this type may be used where appropriate in other than Train Order areas.




Figure 2-5: MECHANICAL POINT INDICATOR

2.6.2 Electrical

Electrical dwarf colour light point indicators are provided to give an indication to the driver that the points in advance are either unlocked (2 red lights) or set and locked for the normal or reverse (left or right white arrow) depicting the direction for train movements.

2.7 Points Setting Indicator

Points Setting Indicators (also known as Points Indicators in the CoP SA) indicate the setting of points on the Main Line, where the points can be locked in both positions.

Points Setting Indicators do not indicate that the points are locked and are often provided in conjunction with another display of points-locked status.

The indication is displayed by either:

- A retro-reflective inclined green arrow.
- A retro-reflective yellow dumbbell, or
- A retro-reflective red dumbbell.

The indicator body rotates by 90° around a vertical axis as the points change position to provide the relevant indication. The indication is double sided.




Figure 2-6A: POINTS SETTING INDICATOR





Figure 2-6B: POINT SETTING INDICATOR SCENARIOS

2.7.1 Point Setting Indicators - not on the main line

Yellow Circle – indicates that the crossing loop points are set for the crossing loop or yard points are set straight ahead.



White Square – indicates the crossing loop points are set for the siding or yard points are set for the turnout route.



2.8 Main Line Indicators/Repeaters

A Main Line Indicator is not a signal and does not provide a movement Authority.

A Main Line Indicator displays a colour-light indication to indicate that the infrastructure conditions are correct for the train to move past the indicator. This includes points (set and locked for the Main Line) and active level crossings (already operating or will operate on train approach).

The Main Line Indicator shall be positioned alongside the facing points, and where possible, be visible to approaching trains from a distance of at least 800m.

A pulsating white light indicates that infrastructure conditions are correct for the train to proceed at normal speed. A red light indicates that one or more of the infrastructure items past the main line indicator are not set correctly.

Where the Main Line Indicator reads up to a point where the train may be required to stop, a yellow aspect shall be used. Examples of such a situation include:

1. Where multiple Main Line Indicators are installed at a single train order location, a yellow light is used in the first indicator encountered to indicate that the next main line indicator may be at stop (refer to Principle 3.7).
2. Where a Point Indicator is installed in advance of the Main Line Indicator and the points are not detected by the Main Line Indicator (normally in conjunction with a level crossing located in the centre of a location – refer to Principle 5.2, 5.3, 5.4), or
3. Where the Main Line Indicator reads up to a “STOP” sign (normally at a line terminus – refer to Principle 8).

A white retro-reflective diamond is attached to the indicator post in place of a marker light.

Where Main Line Indicators and motorised points are used, an angled steady white band of lights is used to indicate the facing points are set for the turnout route. This may also be provided at mechanical points where a both-ways lock is used. A route indicator may be provided below the MLI if the indicator reads over multiple routes.

Main Line Indicators are to be named the same as the first motor points or ground frame beyond the indicator. The letter name is to be displayed on the white retro-reflective diamond. Where the indicator is purely for a level crossing, “X” or “Y” may be used.

Where necessary for sighting reasons, a Repeater to a Main Line Indicator may be provided. This is to take the same form as the Main Line Indicator except that the white diamond plate shall have the name 'REPTR' below the Main Line Indicator name and a yellow light is used in place of the red light.

Main Line Indicators may be used where appropriate in other than Train Order areas.




Figure 2-7: MAIN LINE INDICATORS

2.9 Light Indicators

A Light Indicator (also known as Point Enhancer) displays the setting of facing and trailing Main Line points at a Block Location. It may be provided in addition to a reflective Points Setting Indicator. A white retro-reflective diamond may be attached to the Light Indicator post. The Light Indicator may be a single head light unit with a tricolour LED light unit or a multi-head light unit with red, yellow and green LED light units.

The Light Indicator shall be positioned alongside the facing points, and where possible, be visible to approaching trains from a distance of at least 2500m.

Where the sighting distance is less than 2500m, a Light Indicator repeater may be provided. The repeater shall be identified by the letter "R" on the white retro-reflective diamond and repeat the indication displayed on the Light Indicator at the facing points.

The light indications and their meaning are as follows:

- **Steady Green:** The points at both ends of the location are set and locked for the Main Line.
- **Steady Yellow:** The facing points are set and locked for Main Line however the trailing points are not correctly set.
- **Flashing Yellow:** The facing points are set and locked for the Crossing Loop.
- **Red:** Points are not correctly set, the timer for the points is operating or the points track circuit is occupied.




Figure 2-8A: Light Indicator indications




Figure 2-8B: Light Indicator with a tricolour LED Lights




Figure 2-8C: Light Indicator Repeater

2.10 “Start” or “Begin Train Order Working” Sign

Train Order Working signs show the beginning of the territory where the Train Order system of Safeworking applies. They are not normally provided at sidings in train order territory. These signs are retro-reflective with black letters on a white background. The reverse of the sign is coloured non-reflective matt grey.




Figure 2-9: START / BEGIN TRAIN ORDER WORKING SIGN

2.11 “End Train Order Working” sign

End Train Order Working signs define the points beyond which Train Order working no longer applies, and where another system of safeworking is in place. They are not normally provided at sidings in a train order location. These signs have black letters on a white retro-reflective background. The reverse of the sign is coloured non-reflective matt grey.

Above the End Train Order Working sign is mounted a location name sign (black on retro-reflective yellow) with the location name as used for the issue of Train Orders to this point.




Figure 2-10: END TRAIN ORDER WORKING BOARD

2.12 Network Control Boundary Location signs

Begin and End Control signs define the Network Control boundary where an interface boundary exists between two Network Controllers. The signs are placed “back to back” at the Network Control boundary with the respective Network Controllers permitted to issue Authorities to this sign only.

The Begin and End Control signs are retro-reflective with black letters on a white background. The reverse of the signs is coloured non-reflective matt grey. Between the Begin and End Control signs are a location name sign (black on retro-reflective yellow) with the location name as used for the issue of Authorities to this point.

The signs below are an example where the respective Network Controllers are Australian Rail Track Corporation (ARTC) and Country Rail Network (CRN).




Figure 2-11: NETWORK CONTROL BOUNDARY LOCATION SIGNS

2.13 Ground Frames

Ground frames in Train Order areas are usually released by an Operators Key but can be released by a key from a releasing switch or duplex lock where provided.

The lever lock is arranged so that the key may only be removed when the points are locked and are in the normal position. (Where a both ways lock is provided, the points may be locked in either position).

Not all points in Train Order areas are operated by Ground Frames. Points may be operated by use of a Switch-Stand and locked by a safeworking padlock, or through the local operation of motorised points.

Alternatively, a points master key shall be retained in a line-side safe, the location of which shall be as defined in the Operational Specification for that Train Order section.

The key remains in the possession of the train crew for point operation whilst in that Train Order Territory.

Upon exiting train order territory, the master key is returned to a safe and locked.

2.14 Operating Keys

2.14.1 Operators Key

The Operators Key is inscribed "Operators Key", individually numbered and is a controlled personal issue to drivers and other staff who are required to operate points in the normal course of their duties.

2.14.2 Master Key

In some areas, a master key is used to operate points mechanisms. This master key is locked in a line side safe in a position determined by the Operational Specification for the Train Order section.

In this way, the master key is secure, and its availability can be controlled by the network controller and limited to drivers and other staff that are competent to operate the points in the normal course of their duties.

The key shall be returned to the safe upon completion of operations, on exiting the Train Order working area if the train is stabled in any siding away from the main line. The Master Key must be inserted in the points lock for the manually operated points. It is retained in the points lock until the points are returned to normal after completion of shunting activities.

2.14.3 Inspection Key

Where necessary, signal and track maintenance staff are supplied with an inspection or "Master" Master key for the purpose of examining points and associated equipment in their sections or districts.

2.14.4 Safes for Keys

As described briefly in section 2.13, the mechanical points are locked by a Master key which is secured in a lineside safe or safes. The key must be retained by the Rail Traffic Crew until it is returned to a safe. If a train can be stabled without Rail Traffic Crew at a location, then a lineside safe shall be provided at that location.

The safe is contained in a trackside enclosure and can be accessed by the standard safety key type for the jurisdiction.

The trackside enclosure will generally be located in close proximity to the points equipment, or as otherwise determined by the operational specification.

The Master key is obtained by entering a numerical release code into the keypad of the safe. The release code is requested from the train controller and will only be given to competent personnel authorised to carry out this activity.

On fulfilment of the authority, or stabled clear of the main line, the master key should be returned to a safe and the door closed. This action generates a finishing code which must be transmitted to the train controller, who will then enter this into the code generator and record the location as Normal for Train Order working.

2.15 Landmarks

Landmarks may be used within Train Order Working areas for the same purpose as in signalled areas. When passing a landmark, the driver is to be prepared to stop at the indicator or sign ahead.

2.16 Shunting Limit or Stop Signs

“Shunting Limit in Down/Up Direction” or “Stop” signs are provided where appropriate in train order territory and are normally associated with line termini and the interface with signalled locations (refer to Principles 1.3 and 1.6). Where Begin Train Order Working signs are located at the same position as Shunting Limit signs, the “Shunting Limit in Down/Up Direction” (black on white in Train Order areas only) is to be mounted above the Begin Train Order Working sign on the same post.

2.17 Block Location Name Signs

Block location signs are provided for in TOW.

Block Location Name signs may be erected parallel to the track (i.e. only visible from a train that is close-up to the sign) and adjacent to ground frames that operate points into a loop or siding in order to identify the name of the track. These are more important where a siding and a loop exist at the one location in correctly identifying the loop or siding.




Figure 2-12: NAME BOARDS

2.18 Train Order Kilometrage Signs

Signs inscribed with the kilometrage of a specific item may be provided. Where there are existing signs such as “Yard Limit”, “Shunting Limit”, etc, the Train Order Kilometrage sign may be mounted on the same post. The kilometrage shown on these signs must be consistent with that used in the train order computer and shown on the driver’s diagram.




Figure 2-13

2.19 Derailers

Derailers may be provided in TOW territory.

Derailers may be installed within sidings to prevent loose rolling stock from entering the main line section when the points and ground frames are normal.

The derailleurs shall be locked in the derail position as the procedures require for storage of loose or damaged wagons within the siding before restoring the points or ground frame to normal operations.

At other times, where the possibility of loose wagons moving and fouling the main line is not present, the derailleurs should be left in the off position as local operating procedures dictate.

The derailer lock shall take the form of the standard safety key type for the jurisdiction concerned.

3 Types and Layout of Train Order Locations

3.1 Introduction

The generic types and layout of Train Order locations is to be in accordance with the criteria laid out in this principle.

3.2 Types of Train Order Locations - NSW

To allow for different infrastructure configurations within Train Order Working territory in NSW, three generic types of train order location have been defined in the train order computer system. These locations are described below. The selection of a particular location type to be applied at a specific location should be discussed with operational representatives for that area.

Block Location – No Crossing Loop or Siding provided

Block locations are used to divide a long section into two sections to increase the capacity for follow-on movements.

It is not possible to cross trains or shunt at these locations. Yard Limit signs are located 500m apart to provide sufficient overlap for following movements.




Figure 3-1: BLOCK LOCATION – No Crossing Loop or Siding Provided

Block Location - Siding Provided

A Block Location may be provided with non-train order sidings but no Crossing Loop. These locations are used where no practical crossing loop exists at the location, due to track configuration, siding condition, siding ownership or for other reasons, or where it is desired to permit movements (e.g. loading) to take place in the siding without the requirement for a shunt order to be held. These locations are also used to facilitate loading of trains from the Main Line where this is practiced.

Clearance posts are not provided at these locations. Shunt Limit signs are provided and shall be located as required to permit the shunting moves necessary.

Yard Limit signs are located a minimum of 500m beyond the Shunt Limit sign at each end of the location, to provide an appropriate overlap between approaching trains and any shunting moves at the location. Location Ahead signs are positioned 2000m or 2500m or train service braking distance (whichever is the greater) from the Yard Limit sign.




Figure 3-2: BLOCK LOCATION – Siding Provided

Block Location – Crossing Loop Provided

A Block Location may be provided with a Crossing Loop for crossing of trains. Within TMACS territory this loop is considered to be within Train Order Working territory. Within PTOS territory this loop is considered to be outside of Train Order Working territory.

The presence of a Crossing Loop is defined by the provision of clearance posts (a loop that is a siding only will not have clearance posts). Additional sidings may also exist at a crossing location; however, these are considered to be outside of Train Order Working territory.

Shunt Limit signs are provided at all crossing locations and shall be located as required to permit the shunting moves necessary at each location.

Yard limit signs are located a minimum of 500m beyond the Shunt Limit sign at each end of the loop, to provide an appropriate overlap between approaching trains and any shunting moves at the location.

Location signs are positioned 2000m, 2500m, or train service braking distance (whichever is the greater) from the Yard Limit sign.

Train Orders can be issued to the Yard Limit sign, Main Line or Loop Line in either direction. A Train Order to the Main or Loop line must be fulfilled between clearance posts on the respective line. Shunt orders can be issued and apply to the entire area between Shunt Limit signs.




Figure 3-3: BLOCK LOCATION – Crossing Loop Provided

Other Train Order Location Types

In some instances, the infrastructure arrangements at a particular location do not suit the above generic location types and a specific type is required. Examples of these include:

1. Junction Locations, or

2. Junction Locations adjacent to a Network Control boundary location, or
3. Locations adjacent to other train order or signalled locations.
4. Locations adjacent to ATMS locations.

In these instances, it is necessary to discuss the specific arrangements at that location with the relevant operational staff and with the System Administrator for the train orders computer system.

3.3 Mechanical Point Indicators (MPI)

All Main line mechanical points are to have mechanical point indicators, unless Main Line Indicators are provided. Mechanical Point Indicators shall be located at the mechanical points they are indicating

Where mechanical point indicators are operated from the facing point lock, a means is to be provided to prevent the points being run through and damaged in the reverse position. Such a device would be a derail or catchpoint. Trailable point mechanisms do not require this protection. When a derail or catchpoint is provided, a "Derail" or "Catchpoint" white on retro-reflective red background sign is to be provided. Trailable Points are to be provided with a "Trailable Points" notice sign which is to be black on a retro-reflective white background, in accordance with Principle 3 in ESD-05-01.

Mechanical point indicators may also be provided on points located in the Loop line at a crossing location, irrespective of the type of indicator fitted on the Main line points, where it is desirable to reduce the delays involved in drivers checking the position of points. Mechanical Point Indicators are not required on non-interlocked points within sidings (i.e. outside of TOW territory). Refer to Figure 3-4.




Figure 3-4: TRAIN ORDER LOCATION WITH MECHANICAL POINT INDICATORS (MPI)

In some instances, the use of Mechanical Point Indicators may be undesirable. These situations include:

1. Where line speeds are high, thus the sighting time of the indicator is insufficient.
2. At locations known to be affected by fog.
3. Where track curvature or other features obstruct sighting of an indicator located at the points.
4. Where Main Line Indicators are predominantly used at other locations on the line (i.e. for consistency of indication).

In these situations, consideration should be given to the use of Main Line Indicators In lieu of Mechanical Point Indicators.

3.4 Main Line Indicators (MLI)

Main Line Indicators can be used in lieu of MPIs where required for train operations, in conjunction with other infrastructure (e.g. level crossings or motorised points) or in the event of any of the situations described above arising.

Main Line Indicators may be located at the facing points, or not further than 300m before the facing points if required for sighting purposes. A single Main Line Indicator is to be provided at each end of the location, although refer also to Principle 3.8.

All facing points switches and FPL's are to be vitally detected in the Main Line Indicator which leads over the points in the facing direction. All trailing points are also to be detected in the indicators; however, this detection may take a non-vital form providing that the system is configured to fail safe principles. Refer to Figure 3-5.




Figure 3-5: TRAIN ORDER LOOP WITH MAIN LINE INDICATORS (MLI)

3.5 Repeaters to Main Line Indicators

Where necessary for sighting reasons, a Repeater to a Main Line Indicator may be provided. This is to take the same form as the Main Line Indicator except that the white diamond plate shall have the name 'REPTR' below the Main Line Indicator name and a yellow light is used in place of the red light – see Section 1.1.8 – Figure 7.

When a Repeater is used, care must be taken to avoid read-through issues between the Yard Limit sign and the Main Line Indicator repeater. In general, this will require that the Yard Limit sign is not located within 300m of the Repeater.

When a Repeater is installed, the Main Line Indicator should then be placed as close to the points as practical.

Figure 3-6 illustrates the general arrangements.




Figure 3-6: REPEATERS TO MAIN LINE INDICATORS (MLI)

3.6 Closely Spaced Train Order Locations

Where sidings or loops are closely spaced, the following arrangements may be applied:

1. Where, for operational reasons, it is desired to provide a train order section between the two locations, the arrangement shown in Figure 3-7A may be used. In this situation it is essential to ensure that the Location sign is no closer to the adjacent interlocking than that location's Yard Limit sign.
2. Where there is insufficient distance for the above to apply but is desired to maintain separate train order locations (to permit multiple shunting movements, for example), the locations may be separated by back-to-back Yard Limit signs. The preferred arrangement is shown in

Types and Layout of Train Order Locations

Figure 3-7B. In this situation, Shunt Limit signs are provided 500m from the applicable Yard Limit signs, permitting Train Orders to be issued up to the Yard Limit whilst a Shunt Order is in force at the location. Location signs should be positioned not less than 2km, and not more than 3km, from the Yard Limit sign

- Where there is insufficient space for 2. above to apply but it is still desirable to create separate train order locations (for example, to allow independent shunting at two sidings), the arrangement shown in Figure 3-7C may be used. In this arrangement, since there is not a full overlap between Yard Limit and Shunt Limit signs, it is not permissible to issue a Train Order up to the Yard Limit whilst a Shunt Order is in force at the location and this is to be prevented in the train order computer system. Location signs should be positioned not less than 2km, and not more than 3km, from the Yard Limit sign.

Where the above arrangements are not appropriate due to lack of adequate distance between the two loops, the sidings or loops must be treated as a single train order location.




Figure 3-7A: CLOSELY SPACED TRAIN ORDER LOCATIONS
ARRANGEMENT WITH A TRAIN ORDER SECTION BETWEEN THE LOCATIONS




Figure 3-7B: CLOSELY SPACED TRAIN ORDER LOCATIONS
PREFERRED ARRANGEMENT WITH BACK-TO-BACK YARD LIMITS




Figure 3-7C: CLOSELY SPACED TRAIN ORDER LOCATIONS
ALTERNATIVE ARRANGEMENT WITH BACK-TO-BACK YARD LIMITS

3.7 Provision of Additional Main Line Indicators within Train Order Locations

In certain situations, it may be necessary to provide additional Main Line Indicators to facilitate the movement of trains to and from a train order location and to provide a continuing assurance to the driver that the points remain in the correct position and any level crossing is operating. These situations include:

1. Where the train order location consists of points that are located some distance apart, and
2. Where the train order location includes one or more level crossings with Type F protection.

In this situation, the first indicator repeats the normal indication of the second indicator as well as the checking of all Main line points between the two indicators. A yellow shall be fitted to the first indicator and is displayed when the second indicator displays a stop indication.

Alternatively, to avoid the need to cable between the two indicators a separate landmark may be provided for the second indicator.

Additional indicators are to be provided where the distance from the first indicator to any facing points exceeds 3km, or for specific site and/or operational reasons where a benefit is given to train operation.

A diagram of the basic arrangements is shown in Figure 3-8A.

Figure 3-8B shows the arrangements with landmarks.

Refer also to Principle 5 regarding the treatment of level crossings at train order locations.





Figure 3-8A: PROVISION OF ADDITIONAL INDICATORS WITHIN TRAIN ORDER LOCATIONS



PROVISION OF ADDITIONAL INDICATORS WITHIN TRAIN ORDER LOCATIONS WITH LANDMARKS
 Figure 3-8B: PROVISION OF ADDITIONAL INDICATORS WITHIN TRAIN ORDER LOCATIONS WITH LANDMARKS

3.8 Naming of Ground Frames at Train Order Locations

Ground Frames are to be identified by letter, commencing with the letter 'A', then 'B' and so on from the City end frame, and proceeding towards the Country end. The letters 'I' and 'O' should not be used.

Where a new connection is provided, the next letter after the existing ground frames shall be used. Similarly, when a siding is removed the ground frames are not renumbered.

4 Train Order Locations with Motorised Points

4.1 Introduction

This principle defines a train order location provided with motor operated points to facilitate train movements.

4.2 General Arrangement

The loop is provided with "Location" signs and "Yard Limit" signs according to the principles defined in Principle 3. Main Line Indicators that show both a pulsating white and turnout indications are provided at or within 300m of the facing motor worked points. The trailing ends of the points are protected by colour light point indicators which display either 2 red lights or a white arrow when the points are set for the track the indicator applies to. The arrangements are shown in Figure 4-1. A route indicator may be provided above the Electric Point Indicator where it reads over multiple routes.




Figure 4-1: TRAIN ORDER LOCATION WITH MOTORISED POINTS

4.3 Track Locking

Track circuits are to be provided over the motor points for track locking of the points motor. Track circuiting is to be provided over the Main line between the point ends to hold the trailing end once a train has passed the facing Main Line Indicator displaying a pulsating white indication.

Release of this locking, when required, is to be in conjunction with a track time release and Operators Key to activate local pushbuttons. Once a train has seen a pulsating white or turnout indication, approach locking is to be applied.

4.3.1 Types of track circuits used for Track Locking

Axle counters are the default selection for this function.

HVI or other track circuits may be considered as an alternative for track locking on these TOW situations. The specific situation shall be risk assessed considering the frequency of rail traffic over the least used path of the points, the climatic conditions which may lead to rail surface contamination and the performance of the type of track circuit. The Risk Assessment shall be recorded as part of the Design Report for the location.

4.3.2 Extent of Track Circuit Locking

The track circuit for track locking of points shall only extend as far as the clearance point on the turnout. Where there is a second siding turnout off the mainline turnout, the track circuit does not extend onto the clearance point of the second turnout.

The track circuit is only used for track locking of the point motor circuit. It is not included in the aspect of the MLI.

4.4 Point Setting

In general, the interlocking at these locations is to permit the following movements:

1. Up Through train
2. Down Through train
3. Up Train to Loop
4. Down Train to Loop
5. Loop Up Departure (See below)
6. Loop Down Departure (See below)

To retain simple and cost-effective interlocking on site, it will be permissible to remotely set 1 to 4 of the above movements. Cancellation must be performed on site through use of the Operators Key and drivers' pushbuttons. Setting of points can be achieved by:

- a. Control from the locomotive by radio
- b. Control from a remote Control Centre
- c. Drivers pushbuttons

Through movements can be automatically set upon train approach if necessary, although the usual situation will be for both Main Line Indicators to display pulsating white indications simultaneously.

Loop departures would be by drivers' pushbuttons operation on site in conjunction with Operators Key operation. Automatic point normalising is provided upon loop entry or departure.

4.5 Emergency Operation of Points

During failures, points may be operated by an ESML or EOL facility or a safeworking padlock applied to the manual operation levers. The use of the ESML is to ensure that the main line indicators display a red indication when the key or crank is removed for use.

4.6 Use of Repeating Indicators

A pulsating yellow aspect may be provided on repeaters reading up to turnout indication. These repeaters must comply with Principle 3.5.

5 Level Crossings at Train Order Locations

5.1 Introduction

This principle describes the various infrastructure options where a Type 'F' level crossing is situated within or adjacent to a train order location. This principle should be read in conjunction with Principles 9 and 10 in ESD-03-01.

5.2 Arrangement where the Level Crossing is some distance from the Loop/Siding

Where a level crossing is located some distance from the loop or siding at a train order location, the Yard Limit and Shunt Limit signs should be situated to avoid the unnecessary operation of the level crossing.

Preferred arrangements are:

1. If there is sufficient distance between the siding and the level crossing, the Yard Limit sign should be positioned so that a train standing at the sign is clear of a level crossing in the rear and thus does not cause tail-flashing.
2. Alternatively, Yard Limit and Shunt Limit signs should be positioned at the extremities of the level crossing approach tracks so that the level crossing falls between the signs.

These two alternatives are shown in Figures 5-1 and 5-2 respectively.




Figure 5-1: LEVEL CROSSING SOME DISTANCE FROM A TRAIN ORDER LOCATION




Figure 5-2: LEVEL CROSSING SOME DISTANCE FROM A TRAIN ORDER LOCATION ALTERNATIVE ARRANGEMENT

In situations where the above is not possible or causes additional complications (for example, due to the proximity of a second level crossing or train order location), a Main Line Indicator may be used to prevent unnecessary operation of the level crossing. Such an indicator would be

normally at stop, with the indicator cleared as required when a train has an order to proceed. Clearing of the indicator can be achieved by:

- a. Control from the locomotive by radio
- b. Control from a remote Control Centre
- c. Drivers pushbuttons
- d. Whistle activation or other suitable means

Should a Main Line Indicator be required this is to be installed with the same requirements as a Repeater for a Main Line Indicator in Principle 3.5. If the sidings ahead are fitted with Point Indicators, the Main Line Indicator should use a yellow aspect instead of a pulsating white.

Refer to Figure 5-3.




Figure 5-3: LEVEL CROSSING SOME DISTANCE FROM A TRAIN ORDER LOCATION ARRANGEMENT WITH MLI AT LEVEL CROSSING

A Main Line Indicator may also be used to prevent tail-flashing of a level crossing due to a train stopped at a Yard Limit sign. In this arrangement, the indicator would normally show a pulsating white aspect but would revert to red until the departure track circuit re-energised. A separate landmark would normally be required. Refer to Figure 5-4.




Figure 5-4: LEVEL CROSSING SOME DISTANCE FROM A TRAIN ORDER LOCATION ARRANGEMENT WITH MLI TO PREVENT TAIL FLASHING

5.3 Arrangement where the Level Crossing is close to the Loop/Siding

Where a level crossing is located close to the loop / siding such that the level crossing approach track will be occupied in shunting moves, a Main Line Indicator shall be provided.

The Main Line Indicator will normally display a pulsating white light, indicating that the level crossing will operate on train approach. Points at the location are released by Master Key, duplex lock or releasing switch (which is released by Operators key). Taking the Master key, duplex lock or releasing switch will cause the Main Line Indicator to revert to red and the level crossing to cease operation.

Drivers Push Button switches are used to operate the level crossing as required during shunting operations. These are provided at appropriate locations, typically at the points and at the Main Line Indicator. Alternatively, if sufficient space is available for shunting the Shunt Limit sign may be positioned adjacent to the Main Line Indicator.

The Drivers Push Buttons provided for shunting shall operate as detailed below. In figure 5-5A below, operation of the Driver's push button will cause the level crossing to operate for the locomotive or train to shunt across the level crossing and back again. The cancel button is operated to cancel the operation of the level crossing. The train is permitted to shunt past the MLI with a red indication under this situation. The train may only pass the MLI for movements up to the 'Shunt Limit'.

Refer to Figures 5-5A and 5-5B.




Figure 5-5A: LEVEL CROSSING ADJACENT TO A TRAIN ORDER LOCATION




Figure 5-5B: LEVEL CROSSING ADJACENT TO A TRAIN ORDER LOCATION ALTERNATIVE ARRANGEMENT

In some situations, it may be preferable for the Main Line Indicator to normally display a red light and to prove the level crossing operating before the Main Line Indicator clears. Examples where this is appropriate include where there is a higher than usual chance that the level crossing is obstructed, or where the potential consequences of non-operation of the level crossing are higher than usual. In this arrangement, steps must be taken to minimise the potential for anticipation by the driver of the Main Line Indicator clearing on approach.

Refer also to Principles 9 and 10 in ESD-03-01.

5.4 Arrangement with Sidings on each side of the Level Crossing

At locations with sidings on or near the approach track on both sides of a level crossing, some combination of the arrangements described in 5.1 and 5.3 shall generally apply, with the necessary arrangements on each side of the level crossing being considered separately.

To eliminate the need to detect points through the location where Point Indicators are used, a yellow aspect may be used in lieu of pulsating white in Main Line Indicators located at the level

crossing. In this instance, when the points are provided with a point indicator and are located 300m or less from the Main Line Indicator, the ground frame normal is to be proved in the yellow aspect of the Main Line Indicator to prevent a possible 'read through' of the point indicator.

Refer to Figure 5-6.




Figure 5-6: LEVEL CROSSING WITH SIDINGS ON EACH SIDE

5.5 Specific Provisions for Passenger or Stopping Trains

Where passenger or other trains regularly stop on the approach to a level crossing, steps must be taken to prevent the level crossing from operating until the train is ready to proceed (refer to Principle 9 in ESD-03-01). In Train Order Working areas, this requires the Main Line Indicator at the level crossing to be held at stop on the approach of the train. Once the train is ready to proceed, the level crossing may be operated in accordance with Principle 9 in ESD-03-01.

In situations where the stopping move is discrete and regular (typically a passenger train), a timer may be used to hold the Main Line Indicator at stop around the time the stopping move is scheduled to occur. The Main Line Indicator normally displays a pulsating white light at other times.

5.6 Level Crossings at Locations Equipped with Main Line Indicators

Where level crossings with Type 'F' protection are located adjacent to locations equipped with Main Line Indicators, multiple Main Line Indicators will be required in one or both directions of travel. These shall conform to the requirements of Principle 3.7. An example of such an arrangement is shown in Figure 5-7.




Figure 5-7: TRAIN ORDER LOCATION WITH MAIN LINE INDICATORS AND LEVEL CROSSING

6 Junctions at Train Order Locations

6.1 Introduction

This principle describes the infrastructure arrangements to be used at branch line junctions in train order working territory.

6.2 Normal Arrangement

The normal arrangement at a junction within a train order location is to apply standard train order working infrastructure as described in Principle 3. However, this arrangement may result in operational inefficiencies.

Typically, the use of a standard ground frame will require the second person of a train taking the branch line to wait at the junction points until the train is fully clear, then normalise the frame and walk the length of the train to re-join. For a train exiting the branch line, the second person would likewise wait at the junction points until the train is fully clear. The train can then propel to permit the second person to re-join before departing the location.

Where these procedures are unacceptable, or the inefficiencies are undesirable, alternative approaches may be used. These are outlined below.

6.3 Arrangement using Mechanical Trailable Points

Trailable points would typically be used where one route through the junction is to be given priority. The use of trailable points will result in the same operational impact on trains taking the branch line as described above. However, a train exiting the branch line will be able to proceed according to its train order, without the need to stop, set points or propel to collect the second person. For trains using the main line, trailable points are treated in the same way as a normal set of points with a mechanical point indicator.

The application of trailable points is described in Principle 3 in ESD-05-01.

6.4 Arrangement using a Both-Ways Lock

A both ways lock would typically be used where it is desirable to give both routes equal priority through the junction. Using a both ways lock, points may be set and locked in either direction. Trains approaching the location are required to verify the lie of the points and, if necessary, stop and set the points as required. However, there is no requirement to restore the points to their original position and trains may depart directly. If a train approaching the points observes that they are lying correctly for the required movement, there is no need for the train to stop.

6.4.1 Arrangement with Mechanical Indicators

When using a both-ways lock with mechanical indicators, it is necessary to provide both a Mechanical Point Indicator and a Points Setting Indicator. Typically, these may be provided on the same post with the PSI above the MPI. The arrangement is to be confirmed at signal sighting. Alternatively, it may be provided on opposite sides of the track to enable effective sighting.

A means is to be provided to prevent the points being run through and damaged when in the incorrect position for a trailing movement. Such a device would be a derail or catchpoint. As the points can be locked both ways, two devices will be required, one for each trailing move. A "Derail" or "Catchpoint" sign shall be provided for each.

Notice signs are provided on the approach to the points from each direction, stating “CHECK POSITION OF POINTS”, white on retro-reflective red background sign. The position of these notice signs is agreed through signal sighting, but signs are generally located to give the driver sufficient time to stop if the points are incorrectly set. Typically, a permanent speed restriction will also be required in all directions through the location commensurate with the sighting distance available.

A diagram of the arrangements is shown in Figure 6-1.




Figure 6-1: JUNCTION LOCATION WITH BOTH-WAYS LOCK AND MECHANICAL INDICATORS

6.4.2 Arrangement with Main Line Indicators

When using a both-ways lock with Main Line Indicators, a turnout indication (steady white band of lights) is used to indicate the facing points are set for the turnout route. Typically, the increased sighting distance for the Main Line Indicator will alleviate the need for a permanent speed restriction to be applied through the location.

A diagram of the arrangement is shown in Figure 6-2.




Figure 6-2: JUNCTION LOCATION WITH BOTH-WAYS LOCK AND MAIN LINE INDICATORS

6.5 Arrangement using Motorised Points

Motorised points may be used at a junction to provide greater efficiency of operation. The arrangement of infrastructure is generally in accordance with Principle 1.8.

Points would normally be set for the main line movement. For moves to and from the branch line, point setting can be achieved by:

- a. Control from the locomotive by radio
- b. Control from a remote Control Centre

c. Drivers pushbuttons.

Automatic point normalising is provided on train departure.

For trailing moves from the branch line, an approach track circuit may be provided to drive the points reverse on train approach. In this situation, an approach track is also to be provided on the main line. The approach of a train on either line will qualify out the other approach track circuit, in order to prevent the points being driven reverse when a main line train is approaching. To avoid problems where one train is waiting at the Yard Limit sign for another to pass the location, approach track circuits must not extend beyond the Yard Limit sign on either line.

Refer to Figure 6-3.




Figure 6-3: JUNCTION LOCATION WITH MOTORISED POINTS

7 Arrangements of Infrastructure at Train Order Boundaries

7.1 Introduction

This principle details the specific arrangement of infrastructure between a train order section and a signalled area.

7.2 Arrangement where Shunting Outside of the Home Signal is Not Required

If trains approaching a signalled interlocking from a train order section will not encounter another train order location, a landmark is to be provided before the home signal in the normal way. (If circumstances require, this may be a distant signal).

The "End Train Order Working" sign is to be located adjacent to the home signal. The location name sign is to be mounted above the End Train Order Working sign.

The starting signal into the train order section is to display a pulsating white indication in lieu of a green light.

A sign inscribed "DO NOT PASS THIS POINT WITHOUT AN AUTHORITY" is to be provided adjacent to the Starting Signal.

The "Begin Train Order Working" sign is located adjacent to the "End Train Order Working" sign.

A diagram of the arrangements is shown in Figure 7-1.




Figure 7-1: TRAIN ORDER SECTION ADJACENT TO SIGNALLED AREA

7.3 Arrangement where Shunting Outside the Home Signal is Required

This arrangement may be adopted where it is necessary to shunt outside the home signal, but it is not desired to block the train order section.

A "Yard Limit" sign is to be located a minimum of 2 Km from the home signal and the Location sign is to be positioned 2km or train service braking distance (whichever is the greater) from the Yard Limit sign.

To define the start of the train order location for trains entering from the signalled area, a location name plate is mounted above a Yard Limit sign installed adjacent to the home signal.

In order to discriminate between the signalled location as a termination point for Train Orders and the train order location that exists between the home signal and the "Yard Limit" sign, a separate

location name shall be given to the train order location. This name may be the signalled location name plus "North, South, East or West," or an alternative location name as appropriate.

The starting signal into the train order section is to display a pulsating white indication in lieu of a green light. A sign inscribed "DO NOT PASS THIS POINT WITHOUT AN AUTHORITY" is to be provided adjacent to the Starting Signal.

The "Begin Train Order Working" sign is located adjacent to the "End Train Order Working" sign.

Should a distant signal be required this is to be installed with the same requirements as a Repeater for a Main Line Indicator in Principle 3.5. Distant signals should be track circuited and preferably a three-position type.

A diagram of the arrangements is shown in Figure 7-2.




Figure 7-2: TRAIN ORDER LOCATION ADJACENT TO SIGNALLED AREA


7.4 Arrangement where a Dedicated Starting Signal is provided

This arrangement is used to facilitate shunting without blocking the section. In this instance the shunting move is wholly contained within the signalled location.

The preferred arrangement is to provide a 500m overlap between the home and starting signals and thus between opposing moves (Figure 7-3A). Where this length of overlap is not available (when converting existing lines to Train Order Working), a shorter overlap may be provided or, if the home and starting signals are adjacent, the Begin and End Train Order Working signs may be positioned alongside these signals (Figure 7-3B).

A sign inscribed "DO NOT PROCEED PAST THIS POINT UNLESS IN POSSESSION OF TRAIN ORDER" is to be provided adjacent to the starting signal, where this is not located at the same location as the "Begin Train Order Working" sign.

Arrangements of Infrastructure at Train Order Boundaries



TRAIN ORDER SECTION ADJACENT TO SIGNALLED AREA

Figure 7-3A: TRAIN ORDER SECTION ADJACENT TO SIGNALLED AREA PREFERRED ARRANGEMENT WHERE DEDICATED STARTING SIGNAL PROVIDED




Figure 7-3B: TRAIN ORDER SECTION ADJACENT TO SIGNALLED AREA ALTERNATIVE ARRANGEMENT WHERE DEDICATED STARTING SIGNAL PROVIDED


7.5 Arrangement where a “Shunt Limit” Sign is provided

This arrangement is a variation to 5.4 above and is shown in figures 7-4A & 7-4B. Again, the preferred arrangement is to provide a 500m overlap between the home and starting signals and thus between opposing moves.

It should be noted that a shunting signal is normally required on the Starting Signal for movements up to the Shunting Limit sign. A pulsating white indication is displayed for through trains that would require a Train Order.

A sign inscribed “DO NOT PASS THIS POINT WITHOUT AN AUTHORITY” is to be provided adjacent to the shunting limit sign, where this is not located at the same location as the “Begin Train Order Working” sign.

Arrangements of Infrastructure at Train Order Boundaries



TRAIN ORDER SECTION ADJACENT TO SIGNALLED AREA

Figure 7-4A: TRAIN ORDER SECTION ADJACENT TO SIGNALLED AREA PREFERRED ARRANGEMENT WHERE SHUNT LIMIT BOARD PROVIDED




Figure 7-4B: TRAIN ORDER SECTION ADJACENT TO SIGNALLED AREA ALTERNATIVE ARRANGEMENT WHERE SHUNT LIMIT BOARD PROVIDED

7.6 Arrangement with a Siding within a Train Order Location adjacent to a Signalled Interlocking

Where a siding is located adjacent to a signalled location, a train order location shall be created adjacent to the signalled location to contain the siding. This is a variant to the arrangement described in 5.3, with the arrangement of infrastructure at the location generally in accordance with Principle 3.2.

When the ground frame is provided with a mechanical point indicator, and the frame is 300m or less from the home signal, the ground frame normal is to be proved in the main head aspect of the home signal to prevent a possible 'read through' of the mechanical point indicator.

The pulsating white indication on the starting signal must also detect the points normal.

Should the frame be closer than 300m to the home signal, but the home signal cannot be seen from the ground frame (or beyond), the requirement for proving the ground frame normal in the home signal main aspect may be omitted, however the points detection will still be required in the starting signal pulsating white indication.

Refer to Figures 7-5A and 7-5B.

Arrangements of Infrastructure at Train Order Boundaries




Figure 7-5A: TRAIN ORDER LOCATION ADJACENT TO SIGNALLED AREA




Figure 7-5B: TRAIN ORDER LOCATION ADJACENT TO SIGNALLED AREA

8 Infrastructure Arrangements at Line Termini worked by Train Orders


8.1 Introduction

This principle details the specific infrastructure arrangements between a train order section and a non-signalled location.

8.2 Arrangement where a Train Order Section is adjacent to a Non-Interlocked Area

Where trains are not required to be held outside the non-interlocked area

As trains approaching will not encounter another train order location, a landmark is to be provided a minimum of braking distance from a 'STOP' sign which protects the non-interlocked area. The 'STOP' sign is to be mounted above the "End Train Order Working" sign. Adjacent to this and facing to trains leaving the non-interlocked area is to be the "Begin Train Order Working" sign. The arrangements are shown in Figure 8-1.



TRAIN ORDER LOCATION ADJACENT TO NON-INTERLOCKED AREA


Figure 8-1: TRAIN ORDER LOCATION ADJACENT TO NON-INTERLOCKED AREA

In this arrangement the 'STOP' sign is to be located relatively close to the non-interlocked area so that there is no necessity for a formal safeworking system to control movements from the 'STOP' sign on the single lines before the non-interlocked area. This will be dependent on visibility, and traffic level considerations, and the need for trains to shunt on to the single line without occupying the Train Order section.

Procedures for passing the 'STOP' sign will be defined in the Rules.

Where trains are required to be held outside the non-interlocked area

Where there is a regular need for trains to be held outside the non-interlocked area a train order location may be established. These arrangements are shown in Figure 8-2.



TRAIN ORDER LOCATION ADJACENT TO NON-INTERLOCKED AREA

Figure 8-2: TRAIN ORDER LOCATION ADJACENT TO NON-INTERLOCKED AREA

Criteria for location of the 'STOP' sign are described above.

8.3 Arrangement where Terminus is a Train Order Location

This arrangement requires occupancy of the Main or Loop line to be by authority of a Train Order. Consequently, infrastructure is generally in accordance with Principle 3. A diagram is shown for this arrangement in Figure 3.

'STOP' signs may be located where appropriate to protect non-interlocked areas such as shown in Figure 8-3.




Figure 8-3: ARRANGEMENT WHERE TERMINUS IS A TRAIN ORDER LOCATION

9 Infrastructure Arrangements at a Network Control Boundary Location

9.1 Introduction

This principle details the specific infrastructure arrangements at a location where a boundary exists between two Network Controllers.

9.2 General Arrangement

The junction location remains configured and operated as a standard train order junction location and the interface between the Network Controllers is located on the respective line clear of the junction location. A location is created at the boundary defined by Begin and End Control signage, refer 1.1.12.

The train order working system is configured to apply the same principle to the signage as with Begin and End Train Order working signs. The signs are placed “back to back” at the Network Control boundary location with the respective Network Controllers permitted to issue an Authority to this sign only.

The Network Control boundary location is positioned a minimum of one train length from the junction location Yard Limit sign on the respective line.

Before a train proceeds onto the respective line (from the junction location points) it must obtain authority from the opposing Network Controller. An advisory sign is placed at the junction points, adjacent to the ground frame. In Figure 9-1, the example advisory sign indicates the branch line from the interface location is controlled by CRN.




Figure 9-1: TRAIN ORDER LOCATION WHERE A BOUNDARY EXISTS BETWEEN TWO NETWORK CONTROLLERS

10 Train Order Locations with Motorised Points, Light Indicators and ICAPS System

10.1 General Arrangement

The loop shall be provided with "Location" signs and "Yard Limit" signs according to Principle 2. Light Indicators shall indicate the position of the facing and trailing points as defined in Principle 2.8.




Figure 10-1

The points shall be operated by either push buttons located within the control cabinet attached to the wall of the equipment hut or adjacent the indicator or remotely, from the locomotive by the train driver as the train approaches the loop.

As there is no approach locking, other than a track circuit on the points, the remote control operation shall have a level of integrity that ensures that there is a safe approach when the points are set for the loop.

10.2 Track Locking

Track circuits are to be provided over the motor points, which when occupied, secures the points in the position that they are set. With the points set reverse, and occupancy occurs and then clears again, the points shall automatically restore to the normal position following a 90 second timer. During this period of occupancy, the Light Indicator shall display a red indication.

10.3 Point Setting

In general, the train control system at these locations shall permit the following movements:

- a. Up Through train
- b. Down Through train
- c. Up Train to loop
- d. Down Train to loop
- e. Loop Up Departure
- f. Loop Down Departure

Loop departures will be by driver pushbuttons operation only.

The points shall be provided with 'Self Restoring' functionality and shall return to the normal position after the movement, provided the door of the enclosure containing the controls is closed.

The points shall be equipped with 'dual control point machines', which are provided with 2 levers, a selector lever and a hand throw lever.

Train Order Locations with Motorised Points, Light Indicators and ICAPS System

The selector lever shall allow the points to be operated from motor operation to hand operation and then the hand throw lever allows the operation of the points.

The hand throw lever cannot be moved whilst the selector lever is in the motor position. Placing the selector lever into the hand position will disable motor operation of the points and also places the points light indicator to red at that end of the location.

10.4 Operating Points from Local Control

At each end of the loop there shall be a local point control that allows the operation of the points.

The controls shall consist of 3 push buttons to operate the points to either normal or reverse, and a cancel command button. Two indicator lights shall display if the points are occupied and if the points are released for operation.

The push buttons and indicator lights shall be contained within a control box. This control box shall have a switch control within the door. When the door of the box is opened it will place the Light Indicator at that end of the location to red and initiate a 90 second timer during which period the points cannot be operated.

Upon expiry of the timer the pushbuttons can be operated to call the points either normal or reverse, after which the Light Indicator shall show the appropriate indication for either the main line or the loop.

Upon initiating a command by from the pushbutton unit, the points will become locked and no further command can be placed on the controls unless the door is closed and then re-opened upon which the timer sequence will recommence. This shall reset the system and will allow another command to be made.

10.4.1 Push Button Controls:

The following pushbuttons shall be provided to locally operate the points at that end:

Normal (Coloured Green): When selected, operates the points to the 'Normal' position provided no ICAPS command has been entered and the 90-second timer has expired.

Reverse (Coloured Red): When selected, operates the points to the 'Reverse' position no ICAPS command has been entered and the 90-second timer has expired.

Cancel (Coloured Black): After a command has been initiated either remotely or locally and the points are locked, selecting this command shall start the 90-second timer to allow the points to be reset.

10.4.2 Indicator Lights:

Status lights are within the pushbutton unit shall display the status of the points and are labelled as follows:

Track Occupied (Coloured Red): Indicates that the points track is occupied, and the points are locked. This indication may also be displayed if a fault exists on the points

Points Released (Coloured Green): Indicates the 90 second timer has expired, and the points can be operated by the push buttons.

10.5 Operating Points from a Locomotive

Locomotives shall be provided with ICAPS control equipment that allows the driver to operate the points for the crossing loop as indicated on the train authority issued by the train controller.

The equipment shall either be permanently fixed to the locomotive or is portable and can be transferred from locomotive to locomotive.

The equipment shall consist of a text screen and a single control labelled '**Loop_name, select Reverse for loop**' which requires to be pressed once and then again after 3 seconds to set the points that are indicated on the text screen.

The point controls can only be initiated provided the locomotive is within the set limits of the 'strike in' point.

The 'strike in' point shall be located 2km from the facing points of the location, with a length of 3-6km. The train driver may enter a command to call the points reverse for the loop whilst in the 'strike in' point. The system shall be designed so that once the locomotive exits the 'strike in' point no command will be allowed and the local controls will require to be operated to set the points.




Figure 10-2: 'STRIKE IN' POINT LOCATION

The text screen in the locomotive ICAPS control equipment shall only display a text when the movement has entered the 'strike in' point of the loop. This shall be generated utilising Global Positioning coordinates.

Upon selecting the command to enter the loop and successful communication of the command has been received, the light indicator shall restore to 'red' and a 90 second timer shall commence. At expiry of the 90 second timer the points shall then set for the crossing loop and the light indicator shall then display the 'flashing yellow' aspect.

Where applicable, after the movement proceeds over and clears the points track circuit, the points shall restore to the normal position automatically upon the expiry of a 90 second timer.

11 Locations to be considered for normal Rail Vehicle Detection Signalling instead of Train Orders

11.1 Introduction

Certain locations, because of their track complexity, layout and their level crossing protection requirements combined with operational needs, may not be adequately covered with train order infrastructure. Consideration should be given to providing Rail Vehicle Detection Signalling In lieu of Train Orders at these locations.

11.2 Conditions that may not be fulfilled by Train Order Infrastructure

Where the following situations occur, consideration is to be given to normal signalling in lieu of train orders:

- a. Where train movements are more effectively controlled by a Network Controller. This will usually be specified in the Operational Requirements.
- b. Where multiple indicators or signals are required in the one running direction and it is necessary to have one provide a warning that the next signal is displaying a restrictive indication (e.g. stop or turnout).
- c. Where shunting movements are to occur in loops or Main lines by private operators not specifically accredited for Train Order Working or fitted with train radio.
- d. Where multiple level crossings exist and protective main line indicators or signals may require to be cleared without a clearance right through the interlocking, or for shunting purposes.
- e. Where a section has been identified as complex and signalled in middle of two TOW sections then the entire section should be signalled to avoid a signalled section between two TOW areas.
- f. Some combination of the above.

Note:

For new works, Train Order working is not a default method in lieu of rail vehicle detection signalling and may be considered on a case-by-case basis based on the risk assessment and operational & maintenance merits. As a minimum, a risk assessment shall include operations and the signal maintenance engineer or delegate. All identified risks due to additional complexity (e.g. additional points & crossings, level crossings, MLIs) shall be agreed by the business unit and operations. All risks shall be accepted by risk owners. Final decision shall be documented.

Risk assessment and related documents shall be sent for information to standards@artc.com.au